

Learn LabVIEW™ 2013/2014 Fast

A Primer for
Automatic Data
Acquisition



Douglas Stamps, Ph.D.

Visit the following websites to learn more about this book:



[amazon.com](https://www.amazon.com)

[Google books](https://books.google.com)

[BARNES & NOBLE](https://www.barnesandnoble.com)

Contents

Preface	vi
Part 1 Introduction to LabVIEW	1
Chapter 1 LabVIEW for Data Acquisition	2
1.1 What is Automatic Data Acquisition?	2
1.2 What is LabVIEW?	5
1.3 The LabVIEW Environment	5
1.3.1 Starting LabVIEW	6
1.3.2 Front Panel and Block Diagram	6
1.3.3 Pulldown Menus and Keyboard Shortcuts	7
1.3.4 Toolbars	8
1.3.5 Palettes	10
1.4 An Experiential Introduction to LabVIEW	14
1.4.1 Case Structures	16
1.4.2 Data Acquisition: The DAQ Assistant	19
1.4.3 Writing to a Measurement File	24
1.4.4 Timing VIs for Control of VI Execution	28
1.4.5 While Loop	29
1.4.6 Waveform Chart	33
1.4.7 Waveform Graph	36
1.4.8 Data Types	38
1.4.9 Converting Dynamic Data	42
1.4.10 Controlling While Loop Execution	46
1.4.11 Good Housekeeping Tips: Cleaning up the Block Diagram	48
1.4.12 Starting the Finite Measurements Case of the Example VI	48
1.4.13 For Loop	52
1.4.14 Local Variables	55
1.4.15 Documenting VIs	59
1.4.16 Good Housekeeping Tips: Organizing the Front Panel	61
1.4.17 Running and Debugging a VI	63
1.5 LabVIEW Example VIs	68
Part 2 Data Acquisition: LabVIEW Configuration Approach	71
Chapter 2 Analog Signal Measurement and Generation	73
2.1 Analog Signal Basics	73

2.1.1	Signal Measurement System	73
2.1.2	Signal Resolution	75
2.1.3	Signal Sampling Rate	76
2.2	Finite Analog Input using Buffers, Hardware Timing, and Triggering	80
2.2.1	Hardware Timing	80
2.2.2	Buffers	81
2.2.3	Triggers	81
2.2.4	Skill-Development Problem: Finite Analog Input Example VI using Hardware Timing, Buffering, and Triggering	82
2.3	Continuous Analog Input using Hardware Timing, Circular Buffers, and Triggers	93
2.3.1.	Circular Buffer	94
2.3.2.	Skill-Development Problem: Continuous Analog Input Example VI using Hardware Timing, Circular Buffering, and Triggering	95
2.4	Continuous Analog Output using Software Timing	107
2.4.1	Introduction to Analog Output	107
2.4.2	Skill-Development Problem: Non-Buffered, Software-Timed, Continuous Analog Output Example VI	107
2.5	Finite Analog Output using Buffers and Hardware Timing	122
2.6	Continuous Analog Output using Circular Buffers and Hardware Timing	138
2.7	Learn by Doing	154
2.7.1	Proficiency-Development Problem: General Purpose Analog Input	155
2.7.2	Proficiency-Development Problem: Thermocouple Input	162
2.7.3	Proficiency-Development Problem: Strain Gage Input	171
2.7.4	Proficiency-Development Problem: Signal Conditioning Using Filters	186
2.7.5	Proficiency-Development Problem: Analog PID Compensator	199
Chapter 3	Digital Signal Measurement and Generation	212
3.1	Digital Signal Basics	212
3.2	Continuous Digital I/O with Software Timing	213
3.3	Learn by Doing	228
3.3.1	Proficiency-Development Problem: Digital Input/Digital Output Control	228
3.3.2	Proficiency-Development Problem: Analog Input/Digital Output Control with Minimum and Maximum Set Points	236

	3.3.3	Proficiency-Development Problem: Stepper Motor Control	245
	3.3.4	Proficiency-Development Problem: Keypad Scanning	255
Chapter 4		Counters	265
	4.1	Counter Basics	265
	4.2	Counter Input	267
	4.2.1	Introduction to Counter Input Applications	267
	4.2.2	Skill-Development Problem: Continuous Measurement of a Digital Pulse Train's Period	271
	4.3	Counter Output	280
	4.3.1	Introduction to Counter Output Applications	280
	4.3.2	Skill-Development Problem: Pulse Train Generation and Pulse Width Modulation	281
	4.4	Learn by Doing	292
	4.4.1	Proficiency-Development Problem: Inductive Proximity Sensor/Metal Detector	292
	4.4.2	Proficiency-Development Problem: Simple Engine Dynamometer Simulation	296
Index			304